



NELSON ADAMS NACO  
420 S E St.  
San Bernardino, CA 92401  
909-383-0828

**DISPLAY CASE or BULLETIN CASE**  
with  
SLIDING GLASS DOORS or HINGED GLASS DOORS

***SUGGESTED INSTALLATION INSTRUCTIONS FOR  
RECESSED DISPLAY CASES***

Note: Please read all instructions before installing display cases. Materials must be stored, installed and used in environmentally controlled conditions. It is the responsibility of the customer to furnish the required fasteners.

1. Check the opening to make sure it is square and true before installing case.
2. Shim opening on all sides  $\frac{1}{4}$ " for case.
3. Insert case into opening.

Note: 3a: For hinged door units, drill and countersink case frame behind doors all four sides

3b: For sliding door units, drill and countersink case frame behind or through door track all four sides.

4. Drill through frame and case boxes into wall.
5. Secure case with flat heads screws.
6. To install sliding doors: Push top of door up into track and insert the bottom of the door into the lower track

**Note:**

Installation to be done by at least 2 qualified installers.

