



NELSON ADAMS NACO
420 S E St.
SAN BERNARDINO, CA 92401

FHW FULL HEIGHT WRITING WALL PANELS

SUGGESTED INSTALLATION INSTRUCTIONS FOR FULL HEIGHT WRITING WALL PANELS

Note: Please read all instructions before installing Nelson Adams FHW panels. Materials must be stored, installed and used in environmentally controlled conditions. Install Nelson Adams FHW panels level flat against the wall at the height indicated on shop drawings using our NACO standard $\frac{1}{2}$ " J-trim aluminum or another approved equal.

1. Before installing FHW panels inspect the finished wall it should have a 4 or 5 grade finished minimum requirements.
2. Install J-trim on the perimeter J-trim on the top, bottom and sides using 3" long drywall fasteners recommended at 16" o.c. or 24" o.c. Before framing the entire wall make sure that you're able to slide the panel inside the J-trim, insert top part of the panel first then gently drop in the bottom part of panel to the bottom J-trim.
3. Using a trowel apply six 3" circles of construction adhesive or Henry's #237 or #317 on the back of the panel six on the left, six on the middle and six on the right and spread the adhesive the long way of the panel in the center on the ends covering most of the panel to avoid large air spaces. Standard panels are 8'-0" x 4'-0" panel. (Henry's 317 working time 5 minutes, Henry's 237 working time 30 minutes)
4. After adding adhesive to the panel, insert panel into j-trim perimeter frame top first then insert the bottom and slide all the way to one side either left or right and insert the spline joint flat bar in between the panel substrate and repeat the process by inserting the the next spline joint to the following panel repeat this procedure until you're complete with all the panels.
5. After all panels have been installed properly installed, clean up the work area and inspect panel and make sure all vinyl surfaces are clean free if dirt, grease, stains and / or other debris.
6. The subcontractor performing the installation should not be responsible for damages caused by other trades.
7. After walk-thru has been done and accepted by the field superintendent the project should be completed and all close out documents should be requested to the Project Manager in charge of the project. (For special cut outs - see page 2 of 2).

Note: Installation to be done by at least 2 qualified installers.

