



NELSON ADAMS NACO
 420 S E STREET
 SAN BERNARDINO, CA 92401
 P 877-810-4080 / 909-383-0828

TWP TACKWALL PANELS

SUGGESTED INSTALLATION INSTRUCTIONS FOR TACKWALL PANELS

Note: Please read all instructions before installing Nelson Adams TWP panels. Materials must be stored, installed and used in environmentally controlled conditions. Install Nelson Adams TWP panels level flat against the wall at the height indicated on shop drawings using our NACO standard $\frac{1}{2}$ " J-trim aluminum or another approved equal if required.

1. Before installing TWP panels inspect the finished wall it should have a 4 or 5 grade finished minimum requirements.
2. Install J-trim on the perimeter. J-trim on the top, bottom and sides using 3" long drywall fasteners recommended at 16" o.c. or 24" o.c. Before framing the entire wall make sure all miter cuts are tight and presentable.
3. Using a trowel apply six 3" circles of construction adhesive or Henry's #237 or #317 on the back of the panel six on the left, six on the middle and six on the right and spread the adhesive the long way of the panel in the center on the ends covering most of the panel to avoid large air spaces, if you're installing different dye lots, start with number sequence #1 followed by #2 and so on until you're done with the panels. Standard panels sizes vary. (Henry's 317 working time 5 minutes, Henry's 237 working time 30 minutes)
4. After adding adhesive to the panel, insert panel into j-trim perimeter frame top first then insert the bottom and slide all the way to one side either left or right and insert.
5. After all panels have been installed properly installed, clean up the work area and inspect panel and make sure all vinyl surfaces are clean free if dirt, grease, stains and / or other debris.
6. The subcontractor performing the installation should not be responsible for damages caused by other trades.
7. After walk-thru has been done and accepted by the field superintendent the project should be completed and all close out documents should be requested to the Project Manager in charge of the project.

Note: Installation to be done by at least 2 qualified installers.

