



NELSON ADAMS NACO
420 S E STREET
SAN BERNARDINO, CA 92401
PH 877.810.4080 - PH 909.879.0421

TWP TACKWALL PANELS

SUGGESTED INSTALLATION INSTRUCTIONS FOR TACKWALL PANELS

Note: Please read all instructions before installing Nelson Adams TWP panels. Materials must be stored, installed and used in environmentally controlled conditions. Install Nelson Adams TWP panels level flat against the wall at the height indicated on shop drawings. (installation without J-trim)

1. Before installing TWP panels inspect the finished wall it should have a level 5 grade finished minimum requirements.
2. Verify if panels will be installed above the base or floor to ceiling. A) If you're installing panels behind the base, these are commonly installed A.F.F. and to the bottom of your t-mold or suspended ceiling. B) If you're installing above the base use the top of the base as reference point to commence your panel installation, if there's no base installed, verify mounting height and using a chalkline mark the desire height and use that chalkline as reference point.
3. Using a trowel apply six 3" circles of construction adhesive or Henry's #237 or #317 on the back of the panel six on the left, six on the middle and six on the right and spread the adhesive the long way of the panel in the center on the ends covering most of the panel to avoid large air spaces, if you're installing different dye lots, start with number sequence #1 followed by #2 and so on until you're done with the panels. Standard panels sizes vary. (Henry's 317 working time 5 minutes, Henry's 237 working time 30 minutes)
4. After adding adhesive to the panel, you can hold the panel in position with finished nails to avoid the panel from moving, also use a couple of finished nails in between the panels to maintain the same gap through out the entire run.
5. After all panels have been installed properly installed, clean up the work area and inspect panel and make sure all vinyl surfaces are clean free if dirt, grease, stains and / or other debris.
6. The subcontractor performing the installation should not be responsible for damages caused by other trades.
7. After walk-thru has been done and accepted by the field superintendent the project should be completed and all close out documents should be requested to the Project Manager in charge of the project.

Note: Installation to be done by at least 2 qualified installers.

ATTACHMENT DETAIL

EXISTING WALL
LEVE 5 FINISHED

TACKWALL PANEL

HENRY'S 317 OR 237 ADHESIVE

BUTT JOINTS CONDITION
STANDARD

BACKSIDE TACKWALL PANEL